HUB-01 INTERACTIVE CONFIGURATION



DSC 5010
PROGRAMMING

Program Keyswitch zone:

Keypad Display	Enter on Keypad	Comments
Enter Section ___	001	Zone 1 keyswitch.
Enter Data XX	22 #	22 is for Zone Type Keyswitch, XX is previous value # to go back to Enter Section.

Program Output:

Keypad Display	Enter on Keypad	Comments
Enter Section ___	009	To program Output 1.
Enter Data XX	05 #	05 is Armed status, XX is previous value, # to return to Enter Section.

Enable Open/Close Reports:

Keypad Display	Enter on Keypad	Comments
Enter Section ___	361	To program phone 1 call direction.
Toggle Option --------	1 #	1 for alarms.
Enter Section ___	365	Open/Close Communicator Call directions.
Toggle Option --------	1 #	Enable Open/Close Call directions for 1st communicator, # to confirm.
Enter Section ___	380	Open/Close Reporting.
Toggle Option --------	1 #	Open/Close Reporting. Enabled.

Set to Contact ID:

Keypad Display	Enter on Keypad	Comments
Enter Section ___	360	Program Alarm Format.
Enter Data XX	03 #	03 is for CID format, XX is the previous programmed value, # to return to Enter Section.
Enter Section ___	#	To get back to main menu.